

CLEANING AND CARE INSTRUCTIONS FOR SURFACES IN THE ONLEVEL WELLNESS SERIES

To ensure that your ONLEVEL Wellness items retain their beautiful surface surface for a long time, please observe the following care instructions:

Do not use any aggressive, acidic, alkaline, chlorinated or abrasive cleaning agents. We recommend wiping your fittings with a dry cotton cloth after each use. This will prevent limescale and water stains and keep your shower shining brightly. For heavier soiling such as limescale, grease, shower gel, shampoo or soap residue, you can use warm water and a mild citric acid-based cleaner on a soft cotton cloth. Make sure that the cleaning agent is not sprayed directly onto the items, but first onto a soft cotton cloth. Then rinse the fittings with clear, cold water and wipe dry.

When cleaning glass panes, ensure they are supported with one hand to prevent any unintended pressure that could cause damage to the panel.

FOR QUESTIONS OR FURTHER INFORMATION

CALL US AT: +44 0161 804 9500

OR SIMPLY SEND US AN E-MAIL TO: INFO@ONLEVEL-UK.COM